

Exchange Online POP3 Server Settings

The following describes the settings of our products (Multi-function printers/Single-function printers). Use Internet Services to set up the POP3 server of Exchange Online that uses OAuth 2.0 authentication.

Important

- Only one POP3 server can be set. The latest setting will become valid.
- If you have set up the POP3 server of Exchange Online that uses OAuth 2.0 authentication, the settings made on the control panel of the machine will not be enabled.
- IPv6 is not supported.

Administrator Consent on Azure Active Directory

You need to consent in advance to the following actions that the machine takes.

- Consulting users' basic information such as email addresses
- Accessing users' emails

Note

For Azure Active Directory, refer to the official website of Microsoft.

1. Enter the following URL into the address box on the browser, and then press the <Enter> key.
https://login.partner.microsoftonline.cn/common/adminconsent?client_id=29bcab27-3e4a-4cbe-8b20-9243988bd39b
2. Log in as a tenant administrator.
3. The consent screen for the authority is displayed. Confirm the contents and click [Accept].
4. Close the browser, after the consent success screen is displayed.

Settings using Internet Services

1. Log in to Internet Services as system administrator.
2. Set DNS server and Proxy server as necessary.
3. Click [Network] > [Protocols] > [POP3] and enable [Port (Receive Email)].
4. Click [Service Provider] to select [Exchange Online].
5. Change the settings as follows.
[Server Address]: partner.outlook.cn
[Host Name]: login.partner.microsoftonline.cn
[Client ID]: 29bcab27-3e4a-4cbe-8b20-9243988bd39b
[Scope]: https://partner.outlook.cn/POP.AccessAsUser.All offline_access openid email
6. Click [Save].
7. Click [Next] or [Open Authentication Screen], after the Enter Authentication Code screen is displayed.
8. On the input screen, enter the code that is displayed on the Enter Authentication Code screen then click [Next].
9. On the sign-in screen, enter the email address for receiving that is to be set for the machine then click [Next].

10. On the password screen, enter the password of the email for receiving then click [Sign In].

11. Close the browser, after the sign-in success screen is displayed.

January 2023 GM1818E5-1 Edition 1
FUJIFILM Business Innovation Corp.